

### **Mini Graphics Fitting Instructions:**

Ensure panels are clean, (free from dust, wax, oil etc), avoid working in extremely hot or cold temperatures. The graphics need to be fitted DRY.

Larger graphics may need two people to work together.

Carefully remove the vinyl graphics by lifting up the 'application tape' from the silicon release paper backing, making sure that all the vinyl decals are lifted up with it. Avoid finger marks on the vinyl itself. It can then be taken over the vehicle, keeping it taut, and avoiding fabrics, clothing otherwise dust and fluff can be attracted to the static of the vinyl. (Note: If any parts of the graphic refuses to lift, simply place the whole graphic (still on its backing) on a firm surface and rub over the 'application tape' with your finger nail to press the section back against the silicon paper.

Tack the graphics gently on the panel, using a tape measure at this point if required. If it needs repositioning, quickly pull it off and try again.

Once you are happy with the positioning, start to flatten it to the surface using a firm credit card, plastic squeegee or cloth. Working from the centre outwards, press down the vinyl pushing the water/air out towards the edges. If there are any air bubbles, use a pin to carefully pop the bubbles and push the air out.